

## Driver Display




The unique Ashwoods display is placed centrally within the driver's cabin

A clear LED display indicates the status of the system and the varying stages of charge or assist

The LED display also indicates the need to change gear up or down for optimum vehicle performance


### Charge

Surplus power gained from the engine and under braking is drawn from the rear differential via a belt drive. This turns the Motor/Generator charging the Intelligent Power Pack Module (IPPM)



### Assist

Once charged, the Intelligent Power Pack Module (IPPM) powers the Motor/Generator which uses the belt drive to put power back into the system



### Gear Shift Indicator

Vehicle can change gear at lower RPM due to additional torque provided by Hybrid Drive

